

Product Installation Instructions



Rain/Drip Gauge

To complete installation you will need:

- Rain/Drip Gauge (located in your kit)

Instructions

1. Determine approximately how long your sprinkler runs each week.
2. Take the Rain/Drip Gauge from inside your kit and set it in the middle of your lawn.
3. Run the sprinkler for 10 minutes and see how much water accumulates in the gauge.
4. Empty the Rain/Drip Gauge.
5. Now place the Rain/Drip Gauge in another area of your lawn and repeat.